Brake pad Instructions

Rear Ends | Suspensions | Axles | Brakes

ATTENTION: Please inspect current brake pads before installing the new brake pads. Some of our applications require that the pads be ground for clearance. This is to prevent the pads from rubbing the rotor hat or hub. A simple hand held grinder is sufficient to remove this material. The picture below shows before and after for reference.

IN23-42

Brake pad Instructions

Rear Ends | Suspensions | Axles | Brakes

ATTENTION: Please inspect current brake pads before installing the new brake pads. Some of our applications require that the pads be ground for clearance. This is to prevent the pads from rubbing the rotor hat or hub. A simple hand held grinder is sufficient to remove this material. The picture below shows before and after for reference.

IN23-42

Brake pad Instructions

Rear Ends | Suspensions | Axles | Brakes

ATTENTION: Please inspect current brake pads before installing the new brake pads. Some of our applications require that the pads be ground for clearance. This is to prevent the pads from rubbing the rotor hat or hub. A simple hand held grinder is sufficient to remove this material. The picture below shows before and after for reference.

IN23-42